Nuragrid Installation Guide for Turf

- Sweep substrate clear of debris.
 Install Nurajacks and Nuragrid as per Installation Video found <u>HERE</u>. Install additional Nurajacks in the centre of each Safety Grid as required.
- 2. Ensure Nuragrid is flat, firm and stable. Check surface with 1.8m straight edge.
- 3. Install additional Nurajacks as required.
- 4. Ensure Nuragrid layout enables outlets to be accessible for cleaning.
- 5. Roll selected turf onto Nuragrid following manufacturer's instructions.
- 6. Consider screwing perimeter of turf at recommended intervals with 10G x 30mm stainless steel wood screws.
- 7. If installing tiles/pavers, follow Nurajack Nuragrid Installation Guide for tiles/pavers.
- 8. Weight off turf with sand as per manufacturer's instructions, taking care not to allow sand onto tiled/paved areas. Precautions should be taken to minimise sand tracking to drainage outlets.
- 9. For areas with no containment, install Nurajack Tile Edge Trim with 10G x 30mm stainless steel wood screws to perimeter. Install vertical tile as necessary.



