

Nuragrid Installation Guide for Structural Tiles & Pavers

1. Sweep substrate clear of debris.
2. Install Nurajacks and Nuragrid as per Installation Video found [HERE](#).
Install additional Nurajacks in the centre of each Safety Grid as required.
3. Ensure Safety Grid is flat, firm and stable. Check surface with 1.8m straight edge.
4. Ensure Nuragrid layout enables outlets to be accessible for cleaning.
5. Arrange tile/paver layout on Nuragrid to ensure full tiles are over the outlets.
6. Install tiles/pavers with Nurajack Mini Spacer and 3mm Shim in corners. Add additional 3mm Shims depending on tile size and format for tile support.
7. Install Nurajack Tile Cladding Clips around the perimeter to space off vertical surfaces.
8. For areas with no containment, install Nurajack Tile Edge Trim with 10G x 30mm stainless steel wood screws to perimeter and perimeter tile on appropriately sized Nurajack Shim. Install vertical tile as necessary.
(Alternatively consider adhering pavers to the Nuragrid system with approved adhesive.)

